


QUANTUM[®]

MICRO QM05XTF



Quantum QM05XTF SPINNING Reel Part List

Key #	Description	Part No.	Key #	Description	Part No.
1	DRAG KNOB ASSEMBLY	AU332-01	24	CLUTCH BEARING	DQ028-01
2	SPOOL ASSEMBLY	DQ321-01	25	CLUTCH BEARING ADAPTER	DQ190-01
2A	DRAG RETAINER	N/A	26	CLUTCH SLEEVE	DQ139-01
2B	DRAG "D" WASHER	N/A	27	CLUTCH ASSEMBLY	TG063-01
2C	DRAG FRICTION WASHER	N/A	28	CLUTCH SPRING	DQ216-01
2D	DRAG KEY WASHER	N/A	29	PINION GEAR	DQ011-01
2E	SPOOL	N/A	30	MAIN SHAFT	DQ015-01
3	SPOOL FRICTION WASHER	TG039-01	31	ANTI-REVERSE PAWL	DQ074-01
4	CLICK GEAR	BU037-01	32	ANTI-REVERSE SPRING	DQ061-01
5	ROTOR NUT	DQ006-01	33	ANTI-REVERSE SWITCH	TG059-01
6	ROTOR NUT WASHER	CU078-01	34	ANTI-REVERSE SWITCH SCREW	TG135-01
7	ROTOR NUT LOCK SCREW	CH094-01	35	HANDLE SCREW CAP ASSY	DQ249-01
8	ROTOR	DQ009-01	36	BODY	DQ001-01
9	KICK LEVER	DQ019-01	37	BODY REAR COVER	DQ250-01
10	BAIL SPRING	DQ117-01	38	BODY REAR COVER SCREW	BU168-01
11	ARM LEVER COVER	DQ046-01	39	O/S GEAR	DQ053-01
12	ARM LEVER COVER SCREW	DQ085-01	40	O/S SLIDER	DQ025-01
13	LINE ROLLER SCREW	DQ108-01	41	O/S SLIDER GUIDE	DQ078-01
14	ARM LEVER	DQ007-01	42	SLIDER GUIDE SCREW	QH051-01
15	LINE ROLLER WASHER	AU102-01	43	BODY BALL BEARING	CH027-01
16	LINE ROLLER FRICTION WASHER	DQ102-01	44	DRIVE GEAR	DQ012-01
17	LINE ROLLER BUSHING	DQ202-01	45	BODY COVER BALL BEARING	CH027-01
18	BAIL PIVOT SCREW "A"	DQ164-01	46	BODY COVER	DQ023-01
19	LINE ROLLER	DQ004-01	47	BODY COVER SCREW "A"	TG057-01
20	LINE ROLLER BUSHING	DQ202-01	48	BODY COVER SCREW "B"	CU085-01
21	BAIL ASSEMBLY	DQ347-01	49	HANDLE ASSY	DQ318-01
22	STACK RETAINER SCREW	UG094-01	50	MAIN SHAFT SCREW	RQ100-01
23	CLUTCH STACK RETAINER	SP040-51			